



# DeWalt D28110 Pinion Replacement

This will take you through the process of taking apart/accessing gear case components.

Written By: Will Young



## INTRODUCTION

In this guide you will take apart the pinion "head" of the grinder to gain access to components in the gear case.

## Step 1 — Disassembling DeWalt D28110 Gear Case



- Using the T-15 screwdriver, remove the four 22-mm torx screws on the gear case.
- ⚠ Unplug the grinder before any disassembly.

## Step 2



- Pull out the gear case.




### Step 3 — Pinion



- Using the T-15 screwdriver, remove the four torx screws.

### Step 4




- Remove the gear case cover from the gear case.

## Step 5



- Using a 10-mm wrench, remove the hex nut by rotating counter-clockwise.

## Step 6



- Remove the armature assembly from the gear case.
- Remove the pinion from the armature assembly.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-29 07:30:21 PM.